

# CL1X4-D1C3 CC-Link/LT Remote I/O Module

## User's Manual

MODEL	CL1X4-D1C3
MANUAL Number	JY997D10601E
Date	September 2008

### SAFETY PRECAUTIONS

(Read these precautions before using)

Please read this manual carefully and pay special attention to safety in order to handle this product properly. Also pay careful attention to safely and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

### DESIGN PRECAUTIONS



- Configure an interlock circuit in a sequence program so that the system operates on the safety side using the communication status information in the event the data link fails into a communication problem. Otherwise, erroneous output and malfunction may result in accidents.
- Remote input and output can not be switched ON or OFF when a problem occurs in the remote I/O modules. Therefore build an external monitoring circuit that will monitor any input signals that could cause a serious accident.



- Do not have control cables and connection cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.
- Use the module and the connection cable without applying any force on them. Otherwise, such cables may be broken or fail.

### INSTALLATION PRECAUTIONS



- Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the specified torque range. If the screws are too loose, the module may drop from its installation position, short circuit, or malfunction. If the screws are too tight, the screws may be damaged, which may cause the module to drop from its installation position or short circuit.
- Install the module on a flat surface. If the mounting surface has concave and/or convex, an excessive force may be applied on the module, and nonconformity may be caused.

### WIRING PRECAUTIONS



- Perform installation and wiring after disconnecting the power supply at all phases externally. If the power is not disconnected at all phases an electric shock or product damage may result.



- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire, product failure or malfunction.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Attach a warning label (hazard symbol 417-IEC-5036) concerning the electric shock to the location.

### STARTING AND MAINTENANCE PRECAUTIONS



- Do not touch the terminals when the power is ON. It may cause an electric shock or malfunction.
- Perform cleaning the module or retightening of terminal screws after turning OFF the all external power supply for sure. Failure to do so may cause failure or malfunction of the modules



- Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or fire.
- The module case is made of resin; do not drop it or subject it to strong shock. A module damage may result.
- Make sure to switch all phases of the external power supply OFF before installing or removing the module to/from the panel. Failure to do so may cause failure or malfunction of the modules.

### DISPOSAL PRECAUTIONS



- When disposing of this product, treat it as industrial waste.

### TRANSPORTATION AND MAINTENANCE PRECAUTIONS



- During transportation avoid the impact which exceeds a regulated value as the module is a precision instrument. Doing so could cause trouble in the module.
- It is necessary to check the operation of module after transportation, in case of any impact damage. Otherwise, causes the damage of the machine and the accident.

### Note Concerning the CE Marking

This note does not guarantee that an entire mechanical module produced in accordance with the contents of the notification comply with the following standards. Compliance to EMC standards of the entire mechanical module should be checked by the user / manufacturer.

### Standards with which this product complies

Type : Programmable Controller (Open Type Equipment) Remote I/O module  
 Models : Products manufactured:  
 from February 1st, 2004 to April 30th, 2006 are compliant with EN61000-6-4 and EN61131-2:1994+A11:1996+A12:2000 after May 1st, 2006 are compliant with EN61131-2:2003


Electromagnetic Compatibility Standards (EMC)	Remark
EN61000-6-4:2001 Electromagnetic compatibility -Generic standards - Emission standard for Industrial environment	Compliance with all relevant aspects of the standard. (Radiated Emissions and Mains Terminal Voltage Emissions)
EN61131-2:1994/A11:1996/A12:2000 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (RF Immunity, Fast transients, ESD and Damped oscillatory wave)
EN61131-2: 2003 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (Radiated Emissions, Mains Terminal Voltage Emissions, RF immunity, Fast Transients, ESD, Surge, Voltage drops and interruptions, Conducted and Power magnetic fields)

For more details please contact the local Mitsubishi Electric sales site.


- Notes For compliance to EMC regulation.  
 It is necessary to install the CL1 series module in a shielded metal control panel.

### 1. Outline of Product

This product is an open sensor connector type input module connected to CC-Link/LT. This product has four input points (24V DC).



### 2. Name and Setting of Each Part and Terminal Arrangement



Name	Description
PW	ON while the power is supplied.
L RUN	ON while normal operation is executed.
Status indicator LED	L ERR. ON: When a communication error or DIP switch setting error occurred Flickering at a constant interval: When the setting of the DIP switch was changed while the power was supplied (even while the LED is flickering, the operation continues. The new setting becomes valid when the power is turned OFF once, then ON again). Flickering at an intermittent interval: When a terminal resistor is not attached or when the module or a connection cable is affected by noise
Input operation indicator LED	ON while the input is ON. Extinguished while the input is OFF.
Interface	Connector for CC-Link/LT communication line/module power supply (24G/DB/DA/+24V)
Connector for I/O interface	sensor connector for connecting input signals The plug for the connector is an optional. The size of the acceptable electric wire is different according to the plug for the connector used.

Name	Description																										
DIP switch *	Set the 10's digit of the station No. using "STATION NO. 10", "STATION NO. 20" and "STATION NO. 40". Set the 1's digit of the station No. using "STATION NO. 1", "STATION NO. 2", "STATION NO. 4" and "STATION NO. 8". Factory default = All bits are OFF. Make sure to set the station No. in the range from 1 to 64. If any station No. outside the range from 1 to 64 is set, it is regarded as an error and the L ERR. LED lights. Example: When setting the station No. to "32", set the DIP switch as follows.																										
	<table border="1"> <thead> <tr> <th rowspan="2">Station No.</th> <th colspan="4">10's digit</th> <th colspan="4">1's digit</th> </tr> <tr> <th>40</th> <th>20</th> <th>10</th> <th>8</th> <th>4</th> <th>2</th> <th>1</th> <th></th> </tr> </thead> <tbody> <tr> <td>32</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td></td> </tr> </tbody> </table>	Station No.	10's digit				1's digit				40	20	10	8	4	2	1		32	OFF	ON	ON	OFF	OFF	ON	OFF	
Station No.	10's digit				1's digit																						
	40	20	10	8	4	2	1																				
32	OFF	ON	ON	OFF	OFF	ON	OFF																				
0.5ms 1.5ms	Sets the response speed. ON: 0.5 ms (fast response type) OFF: 1.5 ms (standard type)																										

\* Set up using a slotted screwdriver with a tip width of 0.9 mm or less.

### 3. Installation

The CL1X4-D1C3 can be installed to DIN rail or directly installed using mounting screws.


Each installation procedure is described below.

#### 3.1 Installation to DIN rail

When installing the module, align the upper DIN rail installation groove on the module with the DIN rail 1), and press the module on to the DIN rail 2). When removing the module, pull the hook downward for installation to DIN rail 3), then remove the module 4).

#### DIN rail mounting screw pitch

When installing the module to the DIN rail, tighten the mounting screws at the pitch of 200mm(7.87") or less.



Applicable DIN rail	TH35-7.5Fe and TH35-7.5Al Width:35mm
---------------------	---

#### 3.2 Direct installation

Screw-tighten the module by attaching M4 screws to the upper and lower mounting holes (two holes in all) provided in the module. Install the module so that the clearance of 1 to 2mm (0.04" to 0.08") is assured for each module.

Applicable screw	M4 × 0.7mm(0.03") × 16mm(0.63") or more (Tightening torque range: 78 to 108 N-cm)
------------------	--

### 4. Wiring

#### 4.1 Connecting and wiring of connector for I/O interface

Wire the connector for I/O interface (e-CON) according to the following procedure:

- Verify that the plug cover is installed in the plug unit.  
 Caution: Do not push the plug cover into the plug unit before the cable is inserted.  
 Once a plug is pressure-displaced, it can no longer be reused.
- Insert the cable until it makes contact with the plug unit.
  - When inserting the cable, confirm that it has been inserted completely. If the cable is not inserted completely, it may cause contact failures.
  - If the cross section of the cable is not round, the cable cannot be inserted smoothly. Cut the cable tip using pliers, etc., and make it as round as possible, then insert it.
  - When inserting the cable, the cable may stick out from the front of the cover. In such a case, pull the cable backward so that the tip of the cable stays within the plug cover.

3) Using a pliers or special tool, push the plug cover into the plug unit, and pressure-displace it. After performing pressure displacement, verify that the plug cover is securely attached to the plug unit, as shown in the figure at right.


- While performing pressure displacement, the plug cover may rise because it is not latched against the plug unit correctly. This condition indicates that pressure displacement is incomplete. Push the plug cover until it is securely installed in the plug unit.

## 4.2 External wiring

Do the action of the input terminal of CL1X4-D1C3 by using the power supply supplied from the CC-Link/LT interface.

The sensor connected with the input terminal must use the one of the NPN opening collector transistor type.

### External wiring



All 24G pin are connected within the module (common).

The module power and external power supply for the input are supplied by the power adapter or the dedicated power supply.


### Notes:

#### \*1 Bleeder resistor

When connecting a two-wire type sensor or input equipment containing a parallel resistor, select a sensor or equipment whose leakage current is 1.7mA or less.

If the leakage current is more than 1.7mA, connect a bleeder resistor obtained in the following calculation formula.

#### Circuit image



$$R(k\Omega) < \frac{1.7(mA)}{\text{Leakage current}(mA) - 1.7(mA)} \times 5.6(k\Omega)$$

The power capacity W of the bleeder resistor R is as follows:

$$W = \frac{(\text{Input voltage})^2}{R}$$

• Please set the response speed (DIP switch) according to the ON or OFF time of the input signal.

When setting 1.5 ms:

Set both the ON and OFF time of the input signal to 1.5 ms or more.

When setting 0.5 ms:

Set both the ON and OFF time of the input signal to 0.5 ms or more.

## 5. Specifications

### 5.1 General specifications

Item	Specification		
<b>Ambient working temperature</b>	0 to 55°C (32 to 131°F)		
<b>Ambient storage temperature</b>	-25 to 75°C (-13 to 167°F)		
<b>Ambient operating humidity</b>	5 to 95%RH: Dew condensation shall not be considered.		
<b>Ambient storage humidity</b>	5 to 95%RH: Dew condensation shall not be considered.		
<b>Vibration resistance</b>	When intermittent vibration is present		
	Frequency	Acceleration	Half amplitude
	10 to 57Hz	—	0.075mm
	57 to 150Hz	9.8m/s <sup>2</sup>	—
When continuous vibration is present		10 times in each of X, Y and Z directions (for 80 min)	
Frequency	Acceleration		Half amplitude
10 to 57Hz	—		0.035mm
57 to 150Hz	4.9m/s <sup>2</sup>		—
<b>Impact resistance</b>	147 m/s <sup>2</sup> , 3 times in each of X, Y and Z directions		
<b>Operating atmosphere</b>	Corrosive gas shall not be present.		
<b>Operating altitude</b>	2,000m(6561'8") or less (*1)		
<b>Installation place</b>	Inside control panel (*2)		
<b>Over-voltage category</b>	II or less (*3)		
<b>Degree of contamination</b>	2 or less (*4)		

### Notes:

\*1 The module cannot be used in an environment pressurized above the atmospheric pressure which can be generated around the altitude of 0 m. If the module is used in such an environment, it may fail.

\*2 The module can be used in any environment even outside the control panel as far as the requirements of the ambient operating temperature, the ambient operating humidity, etc. are satisfied.

\*3 This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises. Category II applies to equipment for which electrical power is supplied from fixed facilities. The surge voltage withstand level for up to the rated voltage of 300V is 2500V.

\*4 This index indicates the degree of conductive generating substances in the environment in which the module is used. The degree of contamination 2 indicates that contamination is caused by generation of only non-conductive substances.

In this degree, however, temporary conduction may be caused by accidental condensation.


### 5.2 Input specifications

Item	Specification
<b>Input method</b>	DC input (Power supply supplied from CC-Link/LT interface)
<b>Number of inputs</b>	4 points
<b>Isolation method</b>	Isolation with photocoupler
<b>Rated input voltage</b>	24V DC
<b>Rated input current</b>	Approx. 4 mA
<b>Operating voltage range</b>	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
<b>Max. simultaneous ON input points</b>	100% (at 24V DC)
<b>ON voltage/ON current</b>	19 V or more/3 mA or more
<b>OFF voltage/OFF current</b>	11 V or less/1.7 mA or less
<b>Input resistance</b>	5.6 kΩ
<b>Response time</b>	<b>OFF→ON</b>
	0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms).
<b>Response time</b>	<b>ON→OFF</b>
	0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms).
<b>Common wiring method</b>	4 points/1 common (sensor connector 3-wire type)

### 5.3 Performance specifications

Item	Specification	
<b>Module power supply</b>	<b>Voltage</b>	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
	<b>Current consumption</b>	35mA (when all points are ON)
	<b>Initial current</b>	70mA
	<b>Max. allowable momentary power failure period</b>	PS1:1ms
<b>Number of stations occupied</b>	4-, 8- or 16-point mode: 1 station	
<b>Noise durability</b>	500Vp-p	
	Noise width: 1μs Cycle: 25 to 60 Hz (by noise simulator)	
<b>Withstand voltage</b>	500V AC for 1 min between primary area (external DC terminal) and secondary area (internal circuit)	
<b>Isolation resistance</b>	10 MΩ or more between primary area (external DC terminal) and secondary area (internal circuit) by 500V DC megger	
<b>Protection class</b>	IP2X	
<b>I/O part connection method</b>	Connection with terminal block	
<b>Module installation method</b>	DIN rail installation, mounted by screws of type M4 × 0.7mm(0.03") × 16mm(0.63") or larger Can be installed in six directions	
<b>Mass (weight)</b>	0.04 kg (0.09 lbs)	

### 6. Outside Dimensions



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

### Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

### For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A.	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061 U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Av. Paulista 1430, conj.74, Bela Vista CEP: 01311-200 Sao Paulo-SP-Brazil Tel : +55-11-3285-1840	China	Mitsubishi Electric Automation (Shanghai) Ltd. 17F, ChuangKing Financial Center, No. 288 West Nanjing Road, Shanghai China 200003 Tel : +86-21-2322-3030
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No. 105 Wu Kung 3rd RD, Wu-Ku Hsiang, Taipei Hsien, 248, Taiwan Tel : +886-2-2269-2459
U.K.	Mitsubishi Electric Europe B.V. UK Branch Travelers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 3F, 1480-6, Gayang-Dong, Gangseo-Gu, Seoul, 157-200, Korea Tel : +82-2-3800-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch VIALE COLLEONI 7-20041 Agrate Brianza (Milano), Italy Tel : +390-39-80531	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02 Mitsubishi Electric Building, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Ctra. de Rub 76-80-AC, 420, E-08190 Sant Cugat del Valles (Barcelona), Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111, Soi Senbhat 54, T.Kanrayao, A.Kanrayao, Bangkok 10230 Tel : +66-2-517-1526
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France Tel : +33-1-55655568	India	Messung Systems Pvt. Ltd. Sapphire House EL-3 J-Block MIDC Bhosari Pune 411026, India Tel : +91-20-27102000
Russia	Mitsubishi Electric Europe B.V. Moscow Representative Office RU-115054, Moscow, Russia Tel : +7-495-721-2070	Australia	Mitsubishi Electric Australia Pty, Ltd. 343 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777
		South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-9282000

**MITSUBISHI ELECTRIC CORPORATION**  
HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
HIMEJI WORKS : 840, CHIYODA CHO, HIMEJI, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.

**CL1X4-D1C3**  
**CC-Link/LT Remote I/O Module**

Please read this manual thoroughly before starting to use the product and handle the product properly.

**User's Manual**

MODEL	CL1X4-D1C3
MANUAL Number	JY997D10601E
Date	September 2008

**SAFETY PRECAUTIONS**

Please read this manual carefully and pay special attention to safety in order to handle this product properly. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".

- DANGER** Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.
- CAUTION** Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results. In any case, it is important to follow the directions for usage. Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

**DESIGN PRECAUTIONS**

- DANGER** Configure an interlock circuit in a sequence program so that the system operates on the safety side using the communication status information in the event the data link falls into a communication problem. Otherwise, erroneous output and malfunction may result in accidents.
- Remote input and output can not be switched ON or OFF when a problem occurs in the remote I/O modules. Therefore build an external monitoring circuit that will monitor any input signals that could cause a serious accident.

- CAUTION** Do not have control cables and connection cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.
- Use the module and the connection cable without applying any force on them. Otherwise, such cables may be broken or fail.

**INSTALLATION PRECAUTIONS**

- CAUTION** Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the specified torque range. If the screws are too loose, the module may drop from its installation position, short circuit, or malfunction. If the screws are too tight, the screws may be damaged, which may cause the module to drop from its installation position or short circuit.
- Install the module on a flat surface. If the mounting surface has concave and/or convex, an excessive force may be applied on the module, and nonconformity may be caused.

**[WIRING PRECAUTIONS]**

- DANGER** Perform installation and wiring after disconnecting the power supply at all phases externally. If the power is not disconnected at all phases an electric shock or product damage may result.
- CAUTION** Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire, product failure or malfunction.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Attach a warning label (hazard symbol 417-IEC-5036) concerning the electric shock to the location.

**[STARTING AND MAINTENANCE PRECAUTIONS]**

- DANGER** Do not touch the terminals when the power is ON. It may cause an electric shock or malfunction.
- Perform cleaning the module or retightening of terminal screws after turning OFF the all external power supply for sure. Failure to do so may cause failure or malfunction of the modules.

**[CAUTION]**

- Do not disassemble or modify the module. Doing so may cause failure, malfunction, injury, or fire.
- The module case is made of resin; do not drop it or subject it to strong shock. A module damage may result.
- Make sure to switch all phases of the external power supply OFF before installing or removing the module to/from the panel. Failure to do so may cause failure or malfunction of the modules.

**[DISPOSAL PRECAUTIONS]**

- DANGER** When disposing of this product, treat it as industrial waste.

**[TRANSPORTATION AND MAINTENANCE PRECAUTIONS]**

- CAUTION** During transportation avoid the impact which exceeds a regulated value as the module is a precision instrument. Doing so could cause trouble in the module.
- It is necessary to check the operation of module after transportation, in case of any impact damage. Otherwise, causes the damage of the machine and the accident.

**Note Concerning the CE Marking**

This note does not guarantee that an entire mechanical module produced in accordance with the contents of the notification comply with the following standards. Compliance to EMC standards of the entire mechanical module should be checked by the user / manufacturer.


**Standards with which this product complies**  
 Type : Programmable Controller (Open Type Equipment) Remote I/O module  
 Models : Products manufactured from February 1st, 2004 to April 30th, 2006 are compliant with EN61000-6-4 and EN61131-2:1994+A11:1996+A12:2000 after May 1st, 2006 are compliant with EN61131-2:2003

Electromagnetic Compatibility Standards (EMC)	Remark
EN61000-6-4:2001 Electromagnetic compatibility -Generic standards - Emission standard for Industrial environment	Compliance with all relevant aspects of the standard. (Radiated Emissions and Mains Terminal Voltage Emissions)
EN61131-2:1994/A11:1996/A12:2000 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (RF Immunity, Fast Transients, ESD and Damped oscillatory wave)
EN61131-2: 2003 Programmable controllers -Equipment requirements and tests	Compliance with all relevant aspects of the standard. (Radiated Emissions, Mains Terminal Voltage Emissions, RF Immunity, Fast Transients, ESD, Surge, Voltage drops and interruptions, Conducted and Power magnetic fields)


For more details please contact the local Mitsubishi Electric sales site.  
 - Notes For compliance to EMC regulation. It is necessary to install the CL1 series module in a shielded metal control panel.

**1. Outline of Product**

This product is an open sensor connector type input module connected to CC-Link/LT. This product has four input points (24V DC).



**2. Name and Setting of Each Part and Terminal Arrangement**



Name	Description
PW	ON while the power is supplied.
L RUN	ON while normal operation is executed.
Status indicator LED	ON: When a communication error or DIP switch setting error occurred Flickering at a constant interval: While the setting of the DIP switch was changed while the power was supplied (even while the LED is flickering, the operation continues. The new setting becomes valid when the power is turned OFF once, then ON again.) Flickering at an intermittent interval: When a terminal resistor is not attached or when the module or a connection cable is affected by noise
Input operation indicator LED	ON while the input is ON. Extinguished while the input is OFF.
Interface	Connector for CC-Link/LT communication line/module power supply (24G/DB/DA+24V) sensor connector for connecting input signals The plug for the connector is an optional. The size of the acceptable electric wire is different according to the plug for the connector used.
Connector for I/O interface	

Name	Description						
DIP switch *	Set the 10's digit of the station No. using "STATION NO. 10", "STATION NO. 20" and "STATION NO. 40". Set the 1's digit of the station No. using "STATION NO. 1", "STATION NO. 2", "STATION NO. 4" and "STATION NO. 8". Factory default = All bits are OFF. Make sure to set the station No. in the range from 1 to 64. If any station No. outside the range from 1 to 64 is set, it is regarded as an error and the L ERR. LED lights. Example: When setting the station No. to "32", set the DIP switch as follows. <table border="1"> <tr> <th>Station No.</th> <th>10's digit</th> <th>1's digit</th> </tr> <tr> <td>32</td> <td>OFF ON</td> <td>OFF ON OFF ON</td> </tr> </table>	Station No.	10's digit	1's digit	32	OFF ON	OFF ON OFF ON
Station No.	10's digit	1's digit					
32	OFF ON	OFF ON OFF ON					
0.5ms	Sets the response speed.						
1.5ms	ON: 0.5 ms (fast response type) OFF: 1.5 ms (standard type)						

\* Set up using a slotted screwdriver with a tip width of 0.9 mm or less.


**3. Installation**

The CL1X4-D1C3 can be installed to DIN rail or directly installed using mounting screws. Each installation procedure is described below.

**3.1 Installation to DIN rail**

When installing the module, align the upper DIN rail installation groove on the module with the DIN rail 1), and press the module on to the DIN rail 2). When removing the module, pull the hook downward for installation to DIN rail 3), then remove the module 4).

**DIN rail mounting screw pitch**  
 When installing the module to the DIN rail, tighten the mounting screws at the pitch of 200mm(7.87") or less.



Applicable DIN rail	TH35-7.5Fe and TH35-7.5Al Width:35mm
---------------------	---

**3.2 Direct installation**

Screw-tighten the module by attaching M4 screws to the upper and lower mounting holes (two holes in all) provided in the module. Install the module so that the clearance of 1 to 2mm (0.04" to 0.08") is assured for each module.

Applicable screw	M4 x 0.7mm(0.03") x 16mm(0.63") or more (Tightening torque range: 78 to 108 N-cm)
------------------	--

**4. Wiring**

**4.1 Connecting and wiring of connector for I/O interface**

Wire the connector for I/O interface (e-CON) according to the following procedure:


- Verify that the plug cover is installed in the plug unit.  
 Caution: Do not push the plug cover into the plug unit before the cable is inserted.  
 Once a plug is pressure-displaced, it can no longer be reused.
- Insert the cable until it makes contact with the plug unit.  
 - When inserting the cable, confirm that it has been inserted completely. If the cable is not inserted completely, it may cause contact failures.  
 - If the cross section of the cable is not round, the cable cannot be inserted smoothly. Cut the cable tip using pliers, etc., and make it as round as possible, then insert it.  
 - When inserting the cable, the cable may stick out from the front of the cover. In such a case, pull the cable backward so that the tip of the cable stays within the plug cover.

- Using a pliers or special tool, push the plug cover into the plug unit, and pressure-displace it. After performing pressure displacement, verify that the plug cover is securely attached to the plug unit, as shown in the figure at right.

- While performing pressure displacement, the plug cover may rise because it is not latched against the plug unit correctly. This condition indicates that pressure displacement is incomplete. Push the plug cover until it is securely installed in the plug unit.


**4.2 External wiring**

Do the action of the input terminal of CL1X4-D1C3 by using the power supply supplied from the CC-Link/LT interface. The sensor connected with the input terminal must use the one of the NPN opening collector transistor type.



All 24G pin are connected within the module (common). The module power and external power supply for the input are supplied by the power adapter or the dedicated power supply.

- Notes:
- Bleeder resistor**  
 When connecting a two-wire type sensor or input equipment containing a parallel resistor, select a sensor or equipment whose leakage current is 1.7mA or less. If the leakage current is more than 1.7mA, connect a bleeder resistor obtained in the following calculation formula.



The power capacity W of the bleeder resistor R is as follows:  
 $W = \frac{(Input\ voltage)^2}{R}$

- Please set the response speed (DIP switch) according to the ON or OFF time of the input signal.  
 When setting 1.5 ms:  
 Set both the ON and OFF time of the input signal to 1.5 ms or more.  
 When setting 0.5 ms:  
 Set both the ON and OFF time of the input signal to 0.5 ms or more.

**5. Specifications**

**5.1 General specifications**

Item	Specification
<b>Ambient working temperature</b>	0 to 55°C (32 to 131°F)
<b>Ambient storage temperature</b>	-25 to 75°C (-13 to 167°F)
<b>Ambient operating humidity</b>	5 to 95%RH: Dew condensation shall not be considered.
<b>Ambient storage humidity</b>	5 to 95%RH: Dew condensation shall not be considered.
<b>Vibration resistance</b>	When intermittent vibration is present Frequency Acceleration Half amplitude 10 to 57Hz - 0.075mm 57 to 150Hz 9.8m/s <sup>2</sup> - 10 times in each of X, Y and Z directions (for 80 min) When continuous vibration is present Frequency Acceleration Half amplitude 10 to 57Hz - 0.035mm 57 to 150Hz 4.9m/s <sup>2</sup> -
<b>Impact resistance</b>	147 m/s <sup>2</sup> , 3 times in each of X, Y and Z directions
<b>Operating atmosphere</b>	Corrosive gas shall not be present.
<b>Operating altitude</b>	2,000m(6561'8") or less (*1)
<b>Installation place</b>	Inside control panel (*2)
<b>Over-voltage category</b>	II or less (*3)
<b>Degree of contamination</b>	2 or less (*4)

- Notes:
- The module cannot be used in an environment pressurized above the atmospheric pressure which can be generated around the altitude of 0 m. If the module is used in such an environment, it may fail.
  - The module can be used in any environment even outside the control panel as far as the requirements of the ambient operating temperature, the ambient operating humidity, etc. are satisfied.
  - This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises. Category II applies to equipment for which electrical power is supplied from fixed facilities. The surge voltage withstand level for up to the rated voltage of 300V is 2500V.
  - This index indicates the degree of conductive generating substances in the environment in which the module is used. The degree of contamination 2 indicates that contamination is caused by generation of only non-conductive substances. In this degree, however, temporary conduction may be caused by accidental condensation.


**5.2 Input specifications**

Item	Specification
<b>Input method</b>	DC input (Power supply supplied from CC-Link/LT interface)
<b>Number of inputs</b>	4 points
<b>Isolation method</b>	Isolation with photocoupler
<b>Rated input voltage</b>	24V DC
<b>Rated input current</b>	Approx. 4 mA
<b>Operating voltage range</b>	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
<b>Max. simultaneous ON input points</b>	100% (at 24V DC)
<b>ON voltage/ON current</b>	19 V or more/3 mA or more
<b>OFF voltage/OFF current</b>	11 V or less/1.7 mA or less
<b>Input resistance</b>	5.6 kΩ
<b>Response time</b>	OFF→ON 0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms). ON→OFF 0.5ms/1.5 ms or less (at 24V DC) Selected by DIP switch (default value = OFF/1.5ms).
<b>Common wiring method</b>	4 points/1 common (sensor connector 3-wire type)

**5.3 Performance specifications**

Item	Specification	
<b>Module power supply</b>	<b>Voltage</b>	20.4 to 28.8V DC (24V DC -15% to +20%) Ripple ratio: Within 5%
	<b>Current consumption</b>	35mA (when all points are ON)
	<b>Initial current</b>	70mA
<b>Module installation method</b>	<b>Max. allowable momentary power failure period</b>	PS1:1ms
	<b>Number of stations occupied</b>	4-, 8- or 16-point mode: 1 station
<b>Noise durability</b>	500Vp-p Noise width: 1μs Cycle: 25 to 60 Hz (by noise simulator)	
<b>Withstand voltage</b>	500V AC for 1 min between primary area (external DC terminal) and secondary area (internal circuit)	
<b>Isolation resistance</b>	10 MΩ or more between primary area (external DC terminal) and secondary area (internal circuit) by 500V DC megger	
<b>Protection class</b>	IP2X	
<b>I/O part connection method</b>	Connection with terminal block	
<b>Module installation method</b>	DIN rail installation, mounted by screws of type M4 x 0.7mm(0.03") x 16mm(0.63") or larger Can be installed in six directions	
<b>Mass (weight)</b>	0.04 kg (0.09 lbs)	

**6. Outside Dimensions**



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

**Warranty**  
 Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

- For safe use**  
 This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.  
 Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.  
 This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A.	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061 U.S.A. Tel: +1-847-478-2100 MELCO-TEC Av. Paulista 1439, conj.74, Bela Vista CEP: 01311-200 Sao Paulo-SP-Brazil Tel: +55-11-2855-1860	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, HongKong Tel: +852-2887-8870
Brazil	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany Tel: +49-2102-486-0	China	17F, ChuangKong Financial Center, No. 288 West Nanjing Road, Shanghai China 200003 Tel: +86-21-2322-3030 Setayu Enterprise Co., Ltd 8F No. 105 Wu Kung 3rd Rd, Wu-Ku Hsiang, Taipei Hsien, 248, Taiwan Tel: +886-2-2259-2469
Germany	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K. Tel: +44-1707-278100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 3F, 1480-6, Gayang-Dong, Gangeseo-Gu, Seoul, 157-200, Korea Tel: +82-2-3659-8592
U.K.	Mitsubishi Electric Europe B.V. Italian Branch VIALE COLLEONI 7-20041 Agrate Brianza (Milano), Italy Tel: +39-039-490531	Singapore	Mitsubishi Electric Asia Pte., Ltd. 307 Alexandra Road #05-01/02 Mitsubishi Electric Building, Singapore 159943 Tel: +65-6470-2469
Italy	Mitsubishi Electric Europe B.V. Spanish Branch Ctra. de Rub 76-80-AC, 420, E-08190 Sant Cugat del Valles (Barcelona), Spain Tel: +34-93-555-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111, Soi Serthai 54, T.Kannayao, A.Kannayao, Bangkok 10200 Tel: +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France Tel: +33-1-55655588	India	Messung Systems Pvt. Ltd. Sapphire House EL-3 J-Block MIDC Bhasani Pune 411026, India Tel: +91-20-2710200
Russia	Mitsubishi Electric Europe B.V. Moscow Representative Office 62, 6th St. Kosimodianskaya nab. RU-115054, Moscow, Russia Tel: +7-495-721-2070	Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel: +61-2-9684-7777
Spain		South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel: +27-11-49282000