

Analog I/O Slave

CRT1-VAD02SD/MLD
CRT1-VDA02SD/MLD

Instruction Manual

Thank you for purchasing an OMRON CRT1-VAD02SD/MLD / CRT1-VDA02SD/MLD Analog I/O Slave. To ensure safe operation, please be sure to read this document along with the manuals for Analog I/O Slave. Please be sure you are using the most recent versions of the user manuals. Contact your nearest OMRON representative to obtain manuals. Keep this document and all user manuals in a safe location and be sure that they are readily available to the final user of the products.

© OMRON Corporation 2009 All Rights Reserved.

Safety Precautions

Meanings of Signal Words

WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there may be severe property damage.

Caution Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.

Precautions for Correct Use

- The operating environment of the PLC System can have a large effect on the longevity and reliability of the system. Improper operating environments can lead to malfunction, failure, and other unforeseeable problems with the PLC System. Be sure that the operating environment is within the specified conditions of installation and remains within the specified conditions during the life of the system.
- Install correctly according to instructions in the manuals. Improper installation of the Unit may result in malfunction.
- Do not operate the control system in the following locations:
 - Locations subject to direct sunlight.
 - Locations subject to temperatures or humidity outside the range specified in the specifications.
 - Locations subject to condensation as the result of severe changes in temperature.
 - Locations subject to corrosive or flammable gases.
 - Locations subject to dust (especially iron dust) or salts.
 - Locations subject to exposure to water, oil, acid, or chemicals. (excluding the waterproof type of Bit Slave).
 - Locations subject to exposure to oil, acid, or chemicals. (Only for the waterproof type of Bit Slave).
 - Locations subject to shock or vibration.
 - Prevent cables and other substances from unnecessary or accidental pressing on the entry buttons.

SUITABILITY FOR USE

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customer's application. Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to the product.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE APPROPRIATE FOR THE APPLICATION AND THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product Catalog for Warranty and Limitation of Liability.

Warning Symbols

WARNING

Do not attempt to take any Unit apart and do not touch the interior of any Unit while the power is being supplied. In addition, do not turn on electricity in the state that founded a cover. Doing so may result in electric shock.

- Provide safety measures in external slave units, including the following items, to ensure safety in the system if an abnormality occurs due to malfunction of the PLC or another external factor affecting the PLC operation. ("PLC" includes CPU Units, other Units mounted in the PLC, and Slave Unit/Repeater Unit and communication devices) Not doing so may result in serious accidents.
- Emergency stop circuits, interlock circuits, limit circuits, and similar safe measures must be provided in external Slave Unit/Repeater Unit.
- The PLC will turn OFF all outputs when its self-diagnosis function detects any error or when a severe failure alarm (FALS) instruction is executed. As a countermeasure for such errors, external safety measures must be provided to ensure safety in the system.
- The PLC outputs may remain ON or OFF due to deposits on or burning of the output relays, or destruction of the output transistors. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.
- When the 24-V DC output (service power supply) is overloaded or short-circuited, the voltage may drop and result in the outputs being turned OFF. As a countermeasure for such problems, external safety measures must be provided to ensure safety in the system.

The CPU Unit refreshes I/O even when the program is stopped (i.e., even in PROGRAM mode). Confirm safety thoroughly in advance before changing the status of any part of memory allocated to I/O Units, Special I/O Units, or CPU Bus Units. Any changes to the data allocated to any Unit may result in unexpected operation of the loads connected to the Unit. Any of the following operation may result in changes to memory status.

• Changing present values in memory from a Programming Device.

• Transferring I/O memory files from a Memory Card or EM file memory to the CPU Unit.

• Transferring I/O memory from a host computer or from another PLC on a network.

Do not apply the voltage/current outside the specified range to this unit. It may cause a malfunction or fire.



- When transporting the Unit, use special packing boxes and protect it from being exposed to excessive vibration or impact during transportation.
- Do not drop any Unit or subject any Unit to excessive shock or vibration. Otherwise, Unit failure or malfunction may occur.
- Mount the Units securely using DIN Trace Bracket or screws.
- Make sure that all Slave Unit mounting screws and cable ties are tightened to the torque specified in the relevant manuals. Incorrect tightening torque may result in malfunction.
- Make sure that the terminal blocks, communications cables, and other items with locking devices are properly locked into place. Improper locking may result in a malfunction.
- When connecting the Units, ground to 100 Ω min.
- Wire all connections correctly according to instructions in the manuals.
- Always separate Flat Cables for different CompoNet lines by at least 5 mm to prevent unstable operation due to interference. Do not bundle Flat Cables.
- Do not exceed the number of nodes or the number of connected nodes beyond the specifications.
- Do not allow foreign matter to enter the Unit.
- Use the correct wiring tools to wire the Units.
- Confirm the polarity of all terminals before connecting cables and connectors.
- Make sure that all terminal block screws are tightened to the torque specified in the relevant manuals. Incorrect tightening torque may result in malfunction.
- Always use the power supply voltage specified in the user manuals. An incorrect voltage may result in Unit failure.
- Observe the following precautions when wiring the communications cable.
 - Separate the communications cables from the power lines or high-tension lines.
 - Do not bend the communications cables past their natural bending radius or pull on cables.
 - Always lay communications cables inside ducts.
- Take appropriate measures to ensure that the specified power with the rated voltage frequency is supplied. Erratic operation of other pieces where the power supply is unstable. An incorrect power supply may result in malfunction.
- Install external breakers and take other safety measures against short-circuiting in external wiring, etc. Insufficient safety measures against short-circuiting may result in burning.
- Take measures as required by the customer to ensure safety in the event of incorrect, missing, or abnormal signals caused by broken signal lines, momentary power interruptions, or other causes.
- Confirm voltage specifications when wiring communications, the power supply, and I/O crossovers. Incorrect wiring may result in malfunction.




- Do not apply voltages or connect loads to the Output Units in excess of the maximum ratings. Excessive voltage or loads may result in damage.
- After replacing a Unit, resume operation after returning the new CPU Unit and/or Special I/O Units the contents of the DM Area, HR Area, and other data required for resuming operation. Not doing so may result in an unexpected operation.
- Do not check the program for proper execution before actually running it on the Unit. Not checking the program may result in unexpected operation.
- Always turn OFF the power supply to the PLC and Slave Unit/Repeater Unit before attempting any of the following. Not turning OFF the power supply may result in damage.
- Assembling any Units (Expansion Units).
- Removing or attaching terminal blocks and connectors to Slave Unit/Repeater Unit.
- Setting DIP switches or rotary switches.
- Connecting cables or wiring the system.
- Confirm that no adverse effect will occur in the system before attempting any of the following. Not doing so may result in an unexpected operation.
- Changing the operating mode of the PLC.
- Operating the I/O Test Functions.
- Operating the User Adjustment functions on Output Units.
- Touch a grounded piece of metal to discharge static electricity from your body before touching the Unit.
- When replacing parts (relay, etc.), be sure to confirm that the ratings of the new part are correct. Not doing so may result in malfunction or burning.
- Do not attempt to disassemble, repair, or modify any Units. Any attempt to do so may result in malfunction, fire, or electric shock.
- Trim the wire and set the specified torque after setting the rotary switches and wiring. Insufficient tightening torque may result in an inadequate protective structure. (Only for the waterproof type of Bit Slave)
- Take appropriate and sufficient countermeasures when installing systems in the following locations:
 - Locations subject to static electricity or other forms of noise.
 - Locations subject to strong electromagnetic fields.
 - Locations close to power supplies.
 - For design for EMC-compliance, please refer to manual for installation.
 - This is a Class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.
- Do not use thinner for cleaning. Use commercially available alcohol instead.


Precautions for Safe Use

- Do not apply voltages or connect loads to the Output Units in excess of the maximum ratings. Excessive voltage or loads may result in damage.
- After replacing a Unit, resume operation after returning the new CPU Unit and/or Special I/O Units the contents of the DM Area, HR Area, and other data required for resuming operation. Not doing so may result in an unexpected operation.
- Do not check the program for proper execution before actually running it on the Unit. Not checking the program may result in unexpected operation.
- Always turn OFF the power supply to the PLC and Slave Unit/Repeater Unit before attempting any of the following. Not turning OFF the power supply may result in damage.
- Assembling any Units (Expansion Units).
- Replacing parts (relay, etc.).
- Setting DIP switches or rotary switches.
- Connecting cables or wiring the system.
- Confirm that no adverse effect will occur in the system before attempting any of the following. Not doing so may result in an unexpected operation.
- Changing the operating mode of the PLC.
- Operating the I/O Test Functions.
- Operating the User Adjustment functions on Output Units.
- Touch a grounded piece of metal to discharge static electricity from your body before touching the Unit.
- When replacing parts (relay, etc.), be sure to confirm that the ratings of the new part are correct. Not doing so may result in malfunction or burning.
- Trim the wire and set the specified torque after setting the rotary switches and wiring. Insufficient tightening torque may result in an inadequate protective structure. (Only for the waterproof type of Bit Slave)
- Take appropriate and sufficient countermeasures when installing systems in the following locations:
 - Locations subject to static electricity or other forms of noise.
 - Locations subject to strong electromagnetic fields.
 - Locations close to power supplies.
 - For design for EMC-compliance, please refer to manual for installation.
 - This is a Class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.
- Do not use thinner for cleaning. Use commercially available alcohol instead.

Indication part



Indication of Indicator



* This level transition automatically goes to the Standard level.

** This level transition automatically goes to the Initial setting level.

*** This level transition automatically goes to the Special function setting level.

Error indicators

If an error occurs during any level in the MONITOR level group is selected, i.e. it is either in the Standard, Option or Comparator level, the indication automatically changes into the Error code level.

Once the error is resolved, it automatically changes into the Standard level.

On the Error code level, check the problem and take a necessary action.

For details, refer to Operation Manual.

Error code (Indicator No.2)	Problem	Cause and possible corrections
E01	EEPROM sum value error	EEPROM has some data errors. Initialize the setting by the Unit or by CX-Integrator.
E08*	Disconnection detected	The input is disconnected. Check if the wire of the input device to be connected is properly connected.
E09	Analog hardware error	The Slave Unit is broken. Replace it with a new one.
E10	Connection timeout	Communications with the Master Unit is disabled. Check if the cable of the Master Unit is properly connected.
E11	Duplicated address or Repeater configuration error	A node address duplicates. Resolve the duplication, and restart the Slave Unit.
E12	Initialization error	The Slave Unit is broken. Replace it with a new one.
E13	WDT error	The Slave Unit is broken. Replace it with a new one.

Error code (Indicator No.2)	Problem	Cause and possible corrections
E14	Parameter error	A part of parameter has an error. Initialize the setting by the Unit or by CX-Integrator.
E15	SW setting error	The switch setting has an error. Resolve the error by the setting of DIP switches and node addresses, and restart the Slave Unit.
E21	EEPROM hardware error	The Slave Unit is broken. Replace it with a new one.
E29	Expansion Unit hardware error	The Expansion Unit is separated. Check if the Expansion Unit is properly connected. If the error persists, the Expansion Unit is broken. Replace it with a new one.

* Applicable only to analog input units.

Local support office:

OMRON

OMRON Corporation
Control Devices Division H.Q.
Shiokoji Horikawa, Shimogyo-ku,
Kyoto, 600-8530 Japan
Tel: (81)75-344-7109
Fax: (81)75-344-7149

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, NL-2132 JD

Hoofddorp The Netherlands

Tel: (31)2356-81-300

Fax: (31)2356-81-388

OMRON ELECTRONICS LLC
1 East Commerce Drive,
Schaumburg, IL 60173 U.S.A.
Tel: (1)847-843-7900
Fax: (1)847-843-8568

OMRON ASIA PACIFIC PTE. LTD.
83 Clemenceau Avenue,
#11-01, UE Square, Singapore 239920
Tel: (65)6835-3011
Fax: (65)6835-2711

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120 China
Tel: (86)21-5037-2222
Fax: (86)21-5037-2200

Note: Specifications subject to change without notice.